



SEDIMENT FILTER FENCE NOTES

1. SET OUT POSTS ALONG THE LENGTH OF THE PROPOSED FENCE IN THE POSITIONS SHOWN ON THE SITE PLAN SPACE POSTS A MAXIMUM OF 3m APART AND DRIVE THEM AT LEAST 0.6m INTO THE GROUND IF EXTRA-STRENGTH OR SELF-SUPPORTING FABRIC IS USED WITHOUT THE WIRE SUPPORT FENCE. POSTS SPACING MUST NOT EXCEED 1.8m. POSTS FOR SEDIMENT FENCES CAN BE EITHER 0.1m DIAMETER WOOD OR EQUIVALENT 105kg/m STEEL WITH A MINIMUM LENGTH OF 1.2m. STEEL POSTS MUST HAVE PROJECTIONS TO WHICH THE WIRE IS FASTENED.
2. EXCAVATE A TRENCH APPROXIMATELY 0.1m WIDE AND 0.2m DEEP ALONG THE LINE OF POSTS AND UPSLOPE FROM THE BARRIER
3. FASTEN WIRE MESH SECURELY TO THE UPSLOPE SIDE OF THE POSTS. USE HEAVY-DUTY WIRE STAPLES AT LEAST 2.5 CM LONG AND TIE WIRE. EXTEND THE WIRE MESH 0.15m INTO THE TRENCH. WIRE FENCE REINFORCEMENT FOR SEDIMENT FENCES MUST BE A MINIMUM OF 14 GAUGE AND HAVE A MAXIMUM MESH SPACING OF 0.15m
4. FASTEN THE FILTER FABRIC TO THE UPHILL SIDE OF THE FENCE POSTS, AND EXTEND IT 0.2m INTO THE TRENCH. THE HEIGHT OF THE FENCE SHOULD NOT EXCEED 0.6m. DO NOT STAPLE FABRIC ONTO TREES. CUT THE FILTER FABRIC FROM A CONTINUOUS ROLL TO AVOID THE USE OF JOINTS. WHEN JOINTS ARE NECESSARY, SPLICE THE FILTER CLOTH AT A SUPPORT POST, WITH A MINIMUM 0.15m OVERLAP, AND SECURELY FASTEN BOTH ENDS TO THE POST.
5. BACKFILL THE TRENCH OVER THE TOE OF THE FABRIC AND COMPACT THE SOIL.
6. INSPECT AND REPAIR FENCE AFTER EACH RAIN EVENT FOR UNDERCUTTING, SAGGING AND OVERTOPPING



SEDIMENT CONTROL PLAN  
PROPOSED NEW GRANNY FLAT  
No. 22 TUDOR ST BELMORE.

Job	Date	Client	Drawn by	NOTES
	MAY 2023	MR & MRS SAOUMA	JOHN GEORGIOU	1. MINIMISE DISTURBED AREAS. 2. ALL STOCKPILES TO BE CLEAR FROM DRAINS, GUTTERS AND FOOTPATHS. 3. DRAINAGE IS TO BE CONNECTED TO STORMWATER SYSTEM AS SOON AS POSSIBLE.