


www.inviewdesign.com.au


Plant quantities on the planting plan take precedence over indicated on the plant schedule. This design including its associated drawings, images, etc. intellectual property of Inview Design Pty Ltd and must not referenced copied or used without written permission of Invi

Plant Schedule

	Code	Botanical Name	Common Name	Height & Width	Pot Size	Stake			
A	Trees								
	Lit TII	Lagerstroemia india "Tuscarora' Tristaniopsis laurina 'Luscious'	Crepe Myrtle Water Gum	5m x 5m 8m x 5m	75L 75L	Yes Yes			
Ŭ	Shrubs								
	Ssn Gse Lch Pto Wfs	Syzygium 'Straight & Narrow' Grevillea sericea 'Pink Midget' Loropetalum chinense 'China Pink' Pittosporum tobira 'Miss Muffet' Westringia fruticosa 'Smokey'	Lilly Pilly Grevillea Fringe Flower Dwarf Pittosporum Coastal Rosemary	5m x 1.2m 0.4m x 0.5m 2m x 1.5m 1m x 1m 1m x 1m	200mm 200mm 200mm 200mm 200mm	No No No No			
	Grasse	Grasses and Groundcovers							
***	Dss Lta Pna Tja	Dianella 'Silver Streak' Lomandra 'Tanika' Pennesetum alopecuroides 'Nafray' Trachelospermum jasminoides	Native Flax Lily Flax Lily Nafray Star Jasmine	0.5m x 0.5m 0.6m x 0.6m 0.6m x 0.6m 2-4m x 2m	140mm 140mm 140mm 140mm	No No No			









Tree watering 1: 1st initial watering at the time of planting. Quantity of water will be adequate to saturate the root ball to its core.

Tree watering 2: post planting, provide a minimum of 15 litres of water (for tree in a 45 litre pot) to the newly planted tree per 7 days. Water at a slow rate not to displace mulch. For trees in pot size larger than 45 litres, provide quantity of water on third of that pot size.





Tease roots out from root ball


75mm depth approved organic mulch as specified ensure mulch is clear of stem


Topsoil as specified. Topsoil depth varies for garden bed - types. Refer specification for topsoil depths. Apply approved slow release fertiliser as specified

Roughen interface between topsoil and subsoil


Excavate hole to the required size and roughen sides and base of hole. Backfill with approved imported or site topsoil


- Rip subsoil to 200mm depth





	^{client:} Tony Martorano	All dimensions are in millimetres and must be checked on site before commencement of construction or manufacturing of any item. Do not scale off drawing. Copyright remains the property of:		
cies referred to precedence over quantities	site address: 13 Gowlland Parade Panania NSW 2213		po box 3021, bilpin, nsw, 2758 isabel lester	
etc. is the not be f Inview Design	sheet title: Landscape Plan & Details		m. 0416 11 00 58 e. isabel@inviewdesign.com.au	





		Inst	titute	
F	rofess	ional	Membe	r

rev #

Leaen

revisions

Medium: P - Print

Delivery: E - Email

issue

PDF - image format

H - hand

medium delivery

M - Mail/Courier

D - CAD

date

P - print F - Fax

sheet number

.01