

Step 3

Determine the effective slope that will influence bush fire behaviour in each direction

Category	North	East	South	West
Slope under the hazard (over 100m) [in degrees]	upslope/flat	upslope/flat	upslope/flat	upslope/flat
	>0 to 5	>0 to 5	>0 to 5	>0 to 5
	>5 to 10	>5 to 10	>5 to 10	>5 to 10
	>10 to 15	>10 to 15	>10 to 15	>10 to 15
	>15 to 20	>15 to 20	>15 to 20	>15 to 20

Step 4

Determine the FFDI that applies to your local government area. Circle the relevant FFDI below

FFDI: 100 ☐ 80 ☒

Step 5

Match the relevant FFDI, vegetation, distance and slope to determine the required BAL.

Identify the BAL for each direction, select the highest level for the entire building and record below. Note BAL-12.5 is the lowest construction level within the scope of AS3959-2018.

Bush Fire Attack Level: BAL- FZ ☐ BAL- 29 ☐ BAL-12.5 ☐
BAL- 40 ☐ BAL-19 ☐ No requirement ☒

Step 6

Determining BAL construction requirements

Once the appropriate BAL has been determined in Step 5, AS3959-2018 and or/ the NASH Standard 2014 will be used to determine the construction requirements for the proposed design.

Does your proposal meet the construction requirements for the BALs required as per AS3959-2018 and the NASH Standard (2014):

Yes ☒ No ☐