



SEEC

# Wastewater Management: Site & Soil Evaluation & Disposal System Design

**For Proposed Commercial Development at: Lot 5  
DP 655046 No. 344 Park Road, Wallacia**

**Prepared by:**

**Ciaran Bromhead**

**Strategic Environmental and Engineering Consulting (SEEC) Pty Ltd**

**PO Box 1098, Bowral NSW 2576**

**Tel. 02 4862 1633**

**Fax. 02 4862 3088**

**Email [reception@seec.com.au](mailto:reception@seec.com.au)**

**Web [www.seec.com.au](http://www.seec.com.au)**

**SEEC Reference: 20000086**

**19 October 2020**



# SEEC

## Strategic Environmental and Engineering Consulting

PO Box 1098, Bowral, NSW, 2576  
phone: (02) 4862 1633  
fax: (02) 4862 3088  
email: [reception@seec.com.au](mailto:reception@seec.com.au)  
[www.seec.com.au](http://www.seec.com.au)

**Project Reference:** 20000086-WW-02  
**Date of Assessment:** 19/10/2020

**Signed:**

### Document Certification

This report has been developed based on agreed requirements as understood by SEEC at the time of investigation. It applies only to a specific task on the nominated lands. Other interpretations must not be made, including changes in scale or application to other projects. The contents of this report are based on a professional appraisal of the conditions that existed at the time of our investigation. Where subsurface investigations have been done the results are only applicable to the specific sampling or testing locations and only to the depth(s) investigated. Because of natural geological variability, and/or because of possible anthropogenic influences, the subsurface conditions reported can change abruptly. Such changes can also occur after the site investigation. The accuracy of the conditions provided in this report is limited by these possible variations and influences and/or is limited by budget constraints imposed by others and/or by adequate accessibility.

### Copyright

The information, including the intellectual property contained in this document is confidential and proprietary to SEEC. It may be used only by the person, company or organization to whom it is provided for the stated purpose for which it is provided. It must not be given to any other person, company or organization without the prior written approval of a Director of SEEC. SEEC reserves all legal rights and remedies in relation to any infringement of its rights in respect of confidential information. © SEEC

### Document Issue Table

Version	Date	Author	Reviewed	Notes
Draft A	8/04/2020	CB	AM & LO	
0A	8/04/2020	CB	Client	
0B	17/04/2020	CB	Client	
01	28/04/2020	CB	Council	
02 Final	19/10/2020	CB		

## TABLE OF CONTENTS

1	EXECUTIVE SUMMARY .....	1
1.1	Scope of Work .....	1
1.2	Site Description .....	1
1.3	Proposed Wastewater Management System .....	2
1.4	Conclusions and Recommendations .....	2
2	SITE DETAILS .....	5
2.1	Design Wastewater Loading .....	5
3	PHYSICAL SITE ASSESSMENT .....	6
3.1	Climate .....	6
3.2	Flood Potential .....	6
3.3	Exposure .....	6
3.4	Slope Gradient .....	6
3.5	Landform .....	7
3.6	Run on and Seepage .....	7
3.7	Erosion Potential .....	7
3.8	Site Drainage .....	7
3.9	Fill .....	7
3.10	Surface Rock .....	7
3.11	Groundwater Use .....	7
3.12	Vegetation .....	7
3.13	Proximity to Watercourses .....	8
3.14	Land Availability .....	8
3.15	Stock Present .....	8
3.16	Risk of Frost .....	8
4	SOIL ASSESSMENT .....	9
4.1	Geology and Soil Landscape .....	9
4.2	Soil Description .....	9
4.2.1	Soil Profile Descriptions .....	9
4.2.2	Soil Classification and Design Irrigation Rate .....	10
4.3	Soil Constraints .....	10
4.3.1	Soil Depth to a Limiting Layer (e.g. bedrock or watertable) .....	10

4.3.2	Coarse Fragments.....	10
4.3.3	pH of Soils .....	10
4.3.4	Electrical Conductivity .....	11
4.3.5	Emerson Aggregate Test (EAT) .....	11
4.3.6	Phosphorus Sorption .....	11
5	HYDRAULIC AND NUTRIENT BALANCE.....	12
6	RECOMMENDATIONS.....	13
6.1	Wastewater System .....	13
6.2	Sizing of the Disposal System.....	13
6.3	Calculations and References .....	13
6.4	Professional Construction .....	13
6.5	Buffer Distances .....	14
6.6	Detergent Use.....	14
6.7	Water Saving Fixtures.....	14
6.8	Signs .....	14
6.9	Summary of Recommendations .....	14
7	SYSTEM DESIGN.....	16
8	REFERENCES.....	18
9	APPENDICES.....	19
9.1	Appendix 1: Penrith City Council Overland Flow Path.....	19
9.2	Appendix 2: Annual Checklist for Owners .....	22
9.3	Appendix 3: Fact Sheets for Owners .....	23

# 1 EXECUTIVE SUMMARY

## 1.1 Scope of Work

Strategic Environmental and Engineering Consulting (SEEC) has been commissioned by Carlo Ranieri & Associates Pty Ltd, on behalf of the property owners, to provide this wastewater site assessment. It is required to accompany an application for a proposed recycling facility at Lot 5 DP 655046 No. 344 Park Road, Wallacia. At the time of inspection there was an existing residential dwelling onsite (Figure 1). The existing dwelling will be converted into a site office. Wastewater in the existing dwelling is currently being treated in a septic tank. The associated absorption system could not be located during the site inspection. The existing septic tank and absorption system will be decommissioned during this development. An amenities block will be constructed on the northern side of the proposed material recovery facility (Figure 1). Therefore, this assessment is required to show how treated wastewater generated from the site office and amenities block can be sustainably managed onsite.

## 1.2 Site Description

Lot 5 DP 655046 is a 20 ha (approx.) rural lot located on the southern side of Park Road, Wallacia. The proposed recycling facility will occupy the eastern extent of the lot (Figure 1). It will consist of a site office, staff/visitor carpark, truck carpark and resource recovery facility (Figure 1). The proposed Effluent Management Area (EMA) will be located to the west of the resource recovery facility where the site grades at 2% to the west (Figure 1). There is a dam and several drainage depressions affecting this site however the proposed EMA has been located outside of the prescribed buffer distances to them along the natural slope of the land.

According to Penrith City Council's flood information for this site, the EMA is more than 0.5m above the 1% Average Exceedance Probability (AEP) flood height and the corresponding overland flow path. The proposed EMA has been located >40 m away from this feature (Figure 1 and Appendix 1). A search of WaterNSW's ground water map did not identify any bores used for potable water within 250 m of the proposed EMA.

The proposed EMA is currently non-vegetated and has 100 mm of hardstand in the upper soil profile. Hardstand material will need to be stripped from the proposed EMA and the immediate surrounding area. All stockpiled material and debris will need to be cleared from the proposed EMA prior to its commission. A minimum of 200 mm of good quality topsoil must be placed over the entire EMA and a good covering of vegetation (preferably pasture grasses) immediately established. Once vegetation has been established the proposed EMA can be commissioned.

Soil investigations revealed 150 mm of greyish brown clay loam topsoil over light brown medium clay down to 1,200+ mm in Test Pit 1. Test Pit 2 revealed 300 mm of dark brown clay loam topsoil over 400 mm of brown light/medium clay over slightly mottled light brown medium clay down to 1,200+ mm. Test Pit 3 revealed 100 mm of gravely dark brown hardstand material over massive light brown medium clay down to 1,200+ mm. Soil chemistry testing revealed the soils are non-acidic and are unlikely to be dispersive.

### 1.3 Proposed Wastewater Management System

Penrith City Council's *On-site Sewage Management and Greywater Reuse Policy* (2014) was used to calculate the daily expected wastewater load for this development. The figure for "Rural Factories and Shopping Centers" with access to tank water has been used to estimate the likely wastewater load. SEEC has been informed by the client that there will be no more than 26 staff onsite per day, no more than one visitor to the site per day and a total of eight truck drivers attending the site per day. As all staff, truck drivers and visitor will have access to the toilets and basins, the estimated wastewater load is 30 L/person/day. Therefore the design daily wastewater flow has been calculated as 35 persons x 30 L/day = 1050 L/day.

It is proposed to decommission the existing septic tank and absorption system and to install a NSW Health approved Aerated Wastewater Treatment System (AWTS) to secondary-treat all wastewater generated in the proposed site office and proposed amenities block. Secondary-treated effluent from the AWTS will then be disposed of by semi-fixed surface spray irrigation. Hydraulic modelling requires a minimum EMA of 525 m<sup>2</sup>. However, nutrient modelling requires a minimum total EMA of 958 m<sup>2</sup>. This calculation has been based on the assumption that the vegetation over the EMA will be maintained as unmanaged lawn (i.e. pasture grass). This is considered the conservative approach in Penrith City Council. The larger of these areas must be adopted. The property owner proposed to install a total of 1,200 m<sup>2</sup> of irrigation to allow for any unforeseen peak loads. This means the irrigation field will be able to handle a daily wastewater flow of 1315 L/day. Therefore, the total EMA will be 1,200 m<sup>2</sup> of semi-fixed surface spray irrigation built to the requirements of AS/NZS1547:2012 (located in the position shown in Figure 1, to the details in Figure 2).

### 1.4 Conclusions and Recommendations

We conclude the site is suited to dispose secondary-treated effluent by semi-fixed spray irrigation. Specifically, our recommendations are:

1. To decommission the existing septic tank and absorption area;
2. To strip the hardstand material, stock piles and debris off the proposed EMA;
3. To apply a minimum 200 mm of good quality topsoil over the entire EMA and immediately establish a good cover of vegetation (preferably pasture grasses);
4. To install a NSW Health approved AWTS to secondary-treat all wastewater generated in the proposed site office and amenities block;
5. To install at least "three-star" plumbing fixtures, or better, in the proposed site office and amenities block to reduce wastewater loads;
6. To ensure that no other structures (existing or planned) are connected to the proposed AWTS unless the proper approval is sought from Council;
7. As per Figure 2, install 1,200 m<sup>2</sup> of semi-fixed surface spray irrigation built to the requirements of AS/NZS1547:2012 (in the area shown in Figure 1, following the details in Figure 2) to dispose treated wastewater from the AWTS;
8. To maintain a good cover of vegetation (preferably pasture grass) over the entire EMA;
9. To protect the EMA from vehicle access (fence off if necessary);

10. To erect a minimum of two Warning Signs along the edge of the EMA. Refer to Section 6.8;
11. To preferentially select low phosphorus, liquid detergents; and
12. To install and manage the wastewater system according to the details of this report, its appendices and the manufacturer's recommendations.

**Note: This system design might be altered slightly by the Conditions of Consent. It is the responsibility of the owner/builder to check the conditions of consent prior to commencing works.**






Figure 1 - Site map and Effluent Management Area. This Figure must be read in conjunction with the accompanying report by SEEC.



## 2 SITE DETAILS

Table 1 Site details.

Site Address	Lot 5 DP 655046 No. 344 Park Road, Wallacia
GPS Reading	N. -33.873174 E. 150.67821
Developer	Carlo Ranieri & Associates Pty Ltd
Developer Address	203-233 Chain O Ponds Road, Mulgoa
Allotment Size	20 ha (approx.)
Proposed Development	Recycling Facility
Water Supply	Tank
Local Government Authority	Penrith City Council

Table 2 Design wastewater loading rates (Penrith City Council, 2014)

Source	Typical wastewater flow allowance in L/person/day	
	On-site roof water tank supply	Reticulated community or a bore-water supply
<b>Motels/hotels</b> <ul style="list-style-type: none"> <li>• guests, resident staff</li> <li>• non-resident staff</li> <li>• reception rooms</li> <li>• bar trade (per customer)</li> <li>• restaurant (per diner)</li> </ul>	120 30 20 20 20	150 40 30 25 30
<b>Community halls</b> <ul style="list-style-type: none"> <li>• banqueting</li> <li>• meetings</li> </ul>	20 10	35 15
<b>Restaurants (per diner)</b> <ul style="list-style-type: none"> <li>• dinner</li> <li>• lunch</li> </ul>	20 15	30 25
<b>Tea Rooms (per customer)</b> <ul style="list-style-type: none"> <li>• without restroom facilities</li> <li>• with restroom facilities</li> </ul>	10 15	15 25
<b>School (pupils plus staff)</b>	30	40
<b>Rural factories, shopping centres</b>	30	50
<b>Camping grounds</b> <ul style="list-style-type: none"> <li>• fully serviced</li> <li>• recreation areas</li> </ul>	100 50	130 65
<b>Note:</b> 1 These flows are minimum rates unless actual flows from past experience can be demonstrated.		

### 2.1 Design Wastewater Loading

It is proposed to build a Recycling Facility at this site. The facility will have no more than 26 staff onsite per day, no more than one visitor to the site per day and a total of eight truck drivers attending the site per day. As all staff, truck drivers and visitor will have access to the toilets and basins, the estimated wastewater load is 30 L/person/day.

Therefore the design daily wastewater flow has been calculated as 35 persons x 30 L/day = 1050 L/day.

### 3 PHYSICAL SITE ASSESSMENT

The site and soil evaluation has been undertaken following AS/NZS 1547:2012: *On-site Domestic Wastewater Management*, Sections 2.1 & 2.2 of the WaterNSW's *Designing and Installing On-Site Wastewater Systems* (2019) and Appendix 2 of the Environment & Health Protection Guidelines: *On-site Sewage Management for Single Households* (the 'Silver Book', Department of Local Government, 1998).

#### 3.1 Climate

Climate is an important factor in onsite wastewater management. It is particularly important when designing irrigation areas as the dual parameters of incidental rainfall and evaporation have a direct effect on the required size. Areas that have high evaporation and low rainfall are better suited to effluent management by irrigation than those with a cold and/or wet climate. In particularly wet and/or cold areas, wet weather storage might be required, especially during the winter months. We have found the site is in an area where evaporation exceeds rainfall for most, if not all of, the year.

#### 3.2 Flood Potential

It is required to locate all effluent management areas (EMAs) above the 1:20 ARI flood level. This is to reduce the risk of effluent being transported off the site. In addition all electrical components, vents and inspection holes must be located above the 1:100 ARI flood level. This might involve locating the electrical components remote from the tanks, e.g. on a wall or similar. According to Penrith City Council's flood information for this site, the EMA is more than 0.5m above the 1% AEP (equivalent to the 100-year ARI) local catchment overland flow path and has been located 40 m away from this feature (Figure 1 and Appendix 1).

#### 3.3 Exposure

Sun and wind exposure on the EMA must be maximised to help with evaporation. Factors that affect this are local topography, vegetation and the built environment. Improper location of an EMA in the shade can reduce evaporation by up to 30 percent. We have found that the proposed EMA is subject to some shading due to the presence of existing trees. The trees must be removed prior to commissioning the EMA

#### 3.4 Slope Gradient

Slope is an important parameter affecting the choice of effluent management systems. Excessive slope increases the risk of effluent leaving the site, particularly during wet weather. The design irrigation rates are adjusted to account for slope. We have found that slopes in the proposed EMAs are between 0 and 10 percent and so are suitable for all irrigation types. If cost is the main factor then surface spray irrigation might be the most economical.

### 3.5 Landform

Different landforms pose different limitations to effluent management. The risk of run-on and hence the risk of runoff from an EMA is directly related to the type of landform and the position of the EMA on it. We have found that the proposed EMA is either on a crest or an upper side slope. Therefore, the risk of effluent runoff is considered low.

### 3.6 Run on and Seepage

Surface stormwater run-on must not be permitted onto an effluent management area. This is because it could transport effluent offsite and into receiving waters. In addition regular run-on might inhibit vegetative growth. We have found that there is either no risk, or a minimal risk, of stormwater running onto the proposed EMA.

### 3.7 Erosion Potential

Sites where there is active erosion must be avoided for effluent management. We have found that there are no signs of erosion at this well vegetated site.

### 3.8 Site Drainage

An EMA must not be placed in wet or damp areas. This is to reduce the risk of effluent leaving the site by either surface waters or groundwater. The type of vegetation and the condition of the soils give good indications of the site's drainage. We have found that there are no signs of moisture tolerant vegetation such as sedges, ferns or *Juncus* sp. In addition there are no signs of grey mottling in the subsoils within 500 mm of the surface.

### 3.9 Fill

The presence of fill might affect the choice of an effluent management system, particularly if very high or very low permeability soils have been imported. Fill might also be prone to settlement and might also be detrimental to the establishment of good vegetative cover. We have found that there are no signs of fill at this site.

### 3.10 Surface Rock

The presence of frequent rock outcrops and surface rock is usually an indication of shallow and variable soils and/or erosion. In such conditions it might be necessary to import soil to enable the establishment of a good vegetative cover suitable for irrigation. We have found the site has less than 10 percent rock outcrops.

### 3.11 Groundwater Use

The NSW Department of Health recommends that effluent management areas are not located within 250 m of bores that are used for domestic potable water. A search of WaterNSW's groundwater map did not identify any bores within close proximity to the EMA.

### 3.12 Vegetation

The suitability of the existing vegetation (if any) must be considered. The most common, and one of the most suitable, types of vegetation for effluent management is turf. Turf efficiently covers large areas and provides a good opportunity for evapotranspiration and

nutrient uptake (particularly nitrogen). Some native vegetation, particularly that which has developed on poor sandy soils, will not respond well to nutrient-rich wastewater and, if possible, must be avoided or replaced with more suitable species. We have found there is no vegetation over the proposed EMA. It will be necessary to establish a good cover of lawn grasses over the entire EMA prior to commissioning it.

### **3.13 Proximity to Watercourses**

The proximity of natural watercourses or dams is one of the most important factors in the selection of an EMA. It will be necessary to maintain buffers anywhere from 40 m to 150 m between the EMA and a watercourse or dam.

A 40 m buffer is required between an EMA and a drainage depression or a dam, a 100 m buffer is required from a permanent or an intermittent watercourse.

Section 6.5 provides further information on buffer distances.

There will be two Onsite Detention Basins (OSDs) constructed in proximity to the proposed EMA. However the EMA has been located more than 40m away from these features.

### **3.14 Land Availability**

After summarising all of the above, particularly regarding buffer distances, land that is suitable for effluent management on site has been identified. We have found that more than enough land is suitable for effluent management. Figure 1 identifies the area(s) suitable for the effluent management system adopted. Effluent must not be applied outside of those areas, unless at the discretion of the supervising authority.

### **3.15 Stock Present**

Stock can cause damage to irrigation systems and must be kept out of the EMA by fencing or other physical barrier. There are no stock present on this site.

### **3.16 Risk of Frost**

Frost can affect the irrigation system. All distribution pipes must be well buried to protect them. All irrigation pipes must drain after pumping. There is minimal risk of frost on this site.

## 4 SOIL ASSESSMENT

The site and soil evaluation has been undertaken following AS/NZS 1547:2012: *On-site Domestic Wastewater Management* and Appendix 2 of the 'Environment & Health Protection Guidelines: *On-site Sewage Management for Single Households* (the 'Silver Book', Department of Local Government, 1998).

### 4.1 Geology and Soil Landscape

The eSPADE, 2020 mapping identifies the site to be on the Blacktown Soil Landscape.

### 4.2 Soil Description

#### 4.2.1 Soil Profile Descriptions

##### Test Pit 1

Layer 1	0	to	150	Greyish brown clay loam topsoil. 40 mm ribbon.
Layer 2	150	to	1,200+	Massive light brown medium clay. 75-90 mm ribbon.

##### Test Pit 2

Layer 1	0	to	300	Strongly pedal dark brown clay loam topsoil. 35 mm ribbon.
Layer 2	300	to	700	Moderately pedal brown light/medium clay. 75 mm ribbon.
Layer 3	700	to	1,200+	Massive light brown medium clay. Mottled from 800 mm. 75+ mm ribbon.

##### Test Pit 3

Layer 1	0	to	100	Gravelly dark brown hardstand material.
Layer 2	100	to	1,200+	Massive light brown medium clay. 75+ mm ribbon.

### 4.2.2 Soil Classification and Design Irrigation Rate

Table 3 Selected soil classification and corresponding design loading rate.

Soil Category	Soil Texture	Structure	Indicative Permeability		Design Irrigation Rate (DIR) (mm/day) (AS/NZS 1547:2012)
					Drip Irrigation 0-10% Slope
1	Gravels & Sands	Massive	>3.0		
2	Sandy Loams	Weak	>3.0		
		Massive	1.4 - 3.0		
3	Loams	High/ Moderate	1.5 - 3.0		
		Weak or Massive	0.5 - 1.5		
4	Clay Loams	High/ Moderate	0.5 - 1.5		
		Weak	0.12 - 0.5		
		Massive	0.06 - 0.12		
5	Light Clays	Strong	0.12 - 0.5		
		Moderate	0.06 - 0.12		
		Weak/ Massive	< 0.06		
6	Medium to Heavy Clays	Strong	0.06 - 0.5		
		Moderate	< 0.06		
		Weak/ Massive	< 0.06	x	2

## 4.3 Soil Constraints

### 4.3.1 Soil Depth to a Limiting Layer (e.g. bedrock or watertable)

Soil depth is an important factor in choosing a suitable effluent disposal method. The depth of soil is measured to a limiting layer - i.e. bedrock or a periodically high watertable (shown by grey mottling in the soils). Generally, soil is a very good medium for providing treatment to effluent. As the effluent passes through soil it is filtered and there is adsorption of chemicals (particularly phosphorous) onto the soil particles. In addition, this allows time for viruses to die (as they are usually outside of their preferred environment). At least 500 mm of soil is required to provide treatment in an irrigation area. We have found that the soil depth is more than 1.0 m. This is considered a minor limitation

### 4.3.2 Coarse Fragments

Coarse fragments are those over 2 mm in diameter. They can pose limitations to vegetative growth by lowering the soil's ability to supply water and nutrients. We have found that there are less than 20 percent coarse fragments present.

### 4.3.3 pH of Soils

The pH of a soil influences its ability to supply nutrients to vegetation. If the soil is too acidic vegetative growth would be inhibited. We have found that the pH of the soil is more than 6.0. This would not inhibit vegetative growth.



#### 4.3.4 *Electrical Conductivity*

The electrical conductivity (EC) of the soil relates to the amount of salts present. A high salt concentration would inhibit vegetative growth. Electrical conductivity has been measured in deciSemens per metre (dS/m). We have found the electrical conductivity of the soil is less than 4 dS/m. This would not inhibit vegetative growth.

#### 4.3.5 *Emerson Aggregate Test (EAT)*

The Emerson Aggregate Test (EAT) is a measure of soil dispersibility and susceptibility to erosion. It assesses the physical changes that occur to a single ped of soil when immersed in water - specifically whether it slakes and falls apart or disperses and clouds the water. We have classed the soil as Class 7 which means that the soil is unlikely to be dispersive.

#### 4.3.6 *Phosphorus Sorption*

The capacity of a soil to adsorb phosphorus is expressed as its phosphorus sorption capacity. Soils with a high capacity to sorb phosphorous are preferred and can result in smaller application areas. The phosphorous sorption capacity is used in the nutrient balance. Values have been obtained from WaterNSW, 2019.

**TOPSOIL** Estimated P-Sorp (mg/kg) = 400

**SUBSOIL** Estimated P-Sorp (mg/kg) = 600

## 5 HYDRAULIC AND NUTRIENT BALANCE

Wastewater Volume	1050 (L/day)
Vegetation in EMA	Lawn - Unmanaged
Soil in EMA	Med-Heavy Clays

### Hydraulic Balance

$$A = Q / DLR$$

Where:

$$A = \text{Area (m}^2\text{)}$$

$$Q = \text{Wastewater Flow} = 1050 \text{ L/day}$$

$$DLR = \text{Design Irrigation Rate} = 2 \text{ (mm/day)}$$

Area Required:

$$A = 525 \text{ m}^2$$

### Nitrogen Balance

$$A = 3.65(C \times Q) / Lx$$

Where:

$$A = \text{Area (m}^2\text{)}$$

$$C = \text{Concentration of Nutrient} = 30 \text{ mg/L}$$

$$Q = \text{Wastewater Flow} = 1050 \text{ L/day}$$

$$Lx = \text{Critical Loading Rate} = 120 \text{ (Kg/ha/year)}$$

Area Required:

$$A = 958 \text{ m}^2 \text{ of Lawn - Unmanaged}$$

### Phosphorus Balance

$$A = 3.65(C \times Q) / U_R + 0.2d(1 - n_p)G_s X_{\text{sorp}}$$

Basalt soils?

Where:

$$\text{Phosphorus Sorption (X}_{\text{sorp}}\text{)} = 600 \text{ mg/kg}$$

$$\text{Design Soil Depth (d)} = 0.8 \text{ mm}$$

$$\text{Bulk Density} = 1.3 \text{ g/cm}^3$$

$$G_s = 2.65 \text{ g/cm}^3$$

$$\text{P uptake (U}_R\text{)} = 12 \text{ kg/ha/year}$$

$$\text{Concentration of phosphorus} = 12 \text{ mg/L}$$

Area Required:

$$A = 336 \text{ m}^2 \text{ of Lawn - Unmanaged}$$

Adapted from WaterNSW, 2015 and WaterNSW, 2019

## 6 RECOMMENDATIONS

### 6.1 Wastewater System

The following disposal method has been chosen by the client and/or is considered the most suitable:

Semi-fixed surface spray irrigation following treatment in an AWTS.

### 6.2 Sizing of the Disposal System

Hydraulic and nutrient balance modelling has been undertaken to determine the required irrigation area. The design irrigation rate (DIR) given in Section 4.2.2 has been adopted in the hydraulic balance. Hydraulic modelling requires a minimum EMA of 525 m<sup>2</sup>. However, nutrient modelling requires a minimum total EMA of 958 m<sup>2</sup>. This calculation has been based on the assumption that the vegetation over the EMA will be maintained as unmanaged lawn (i.e. pasture grass). This is considered the conservative approach in Penrith City Council. The larger of these areas must be adopted. The property owner proposed to install a total of 1,200 m<sup>2</sup> of irrigation to allow for any unforeseen peak loads. This means the irrigation field will be able to handle a daily wastewater flow of 1315 L/day. Therefore, the total EMA will be 1,200 m<sup>2</sup> of semi-fixed surface spray irrigation built to the requirements of AS/NZS1547:2012 (located in the position shown in Figure 1, to the details in Figure 2).

### 6.3 Calculations and References

The hydraulic balance was calculated as per AS/NZS1547:2012. The nutrient balance was calculated per the WaterNSW document *Neutral or Beneficial Effect on Water Quality Assessment Tool CONSULTANTS AND CONSULTANT ADMINISTRATORS*, 2015. Calculations are based on pages 47-48.

### 6.4 Professional Construction

A typical irrigation design is given in Figure 2, however, a licensed irrigation contractor or plumber must be used to install the irrigation system. Council (or an approved certifier) will be responsible for monitoring the installation and ensuring it is done to the requirements of this document. The irrigation system must incorporate a flushing line connected to either the settling chamber of the AWTS or to a small absorption trench/pit. The effluent distribution pipe from the AWTS to the EMA must be buried at a minimum depth of 300 mm, and/or 500 mm when crossing an access way, and laid to maximise protection against mechanical damage or deformation. The distribution laterals in the EMA must be buried at a minimum depth of 100 mm or 250 mm for Category 6 subsoils. The installer must provide a pump of sufficient capacity to ensure even distribution of effluent throughout the EMA. If required an Auto/Manual Zone Sequencing Valve must be installed to ensure the even distribution of effluent over multiple irrigation fields. The licensed contractor will submit a certificate of installation that will clearly refer to this wastewater design. The certificate will be presented to Council.

## 6.5 Buffer Distances

DLG (1998) (The Silver Book) requires buffers to be maintained from an effluent management area to different land application areas. These are outlined in Table 4.

**Table 4 Specified Buffer Distances.**

All Systems	100 m to permanent waters (rivers and lakes) 40 m to intermittent water features (watercourses, depressions, dams and 1:100 flood level overland flow path) 250 m to potable water bores
Spray Irrigation	6 m if area upslope and 3 m if area downslope of property boundaries and driveways 15 m to dwellings 3 m to walkways and paths 6 m to swimming pools
Subsurface and Drip Irrigation	6 m if area upslope and 3 m if area downslope of swimming pools, boundaries driveways and buildings

## 6.6 Detergent Use

Liquid detergents must be used in the household as powders contain elevated concentrations of salt which could alter the soil's chemistry and reduce its ability to percolate water. All cleaning products must be "Septic Friendly".

## 6.7 Water Saving Fixtures

This design assumes at least three-star rated plumbing fixtures are used in any new building.

## 6.8 Signs

A minimum of two Warning Signs must be installed along the edge of the EMA. The signs shall read "WARNING: RECLAIMED EFFLUENT/RECYCLED WATER, DO NOT DRINK, AVOID CONTACT" or similar. Lettering must be clearly visible from three meters away.

## 6.9 Summary of Recommendations

We conclude the site is suited to dispose secondary-treated effluent by semi-fixed spray irrigation. Specifically, our recommendations are:

1. To decommission the existing septic tank and absorption area;
2. To strip the hardstand material, stock piles and debris off the proposed EMA;
3. To apply a minimum 200 mm of good quality topsoil over the entire EMA and immediately establish a good cover of vegetation (preferably pasture grasses);
4. To install an approved AWTS to secondary-treat all wastewater generated in the proposed site office and amenities block;
5. To install at least "three-star" plumbing fixtures, or better, in the proposed site office and amenities block to reduce wastewater loads;

6. To ensure that no other structures (existing or planned) are connected to the proposed AWTS;
7. As per Figure 2, install 1,200 m<sup>2</sup> of semi-fixed surface spray irrigation built to the requirements of AS/NZS1547:2012 (in the area shown in Figure 1, following the details in Figure 2) to dispose treated wastewater from the AWTS;
8. To maintain a good cover of vegetation (preferably pasture grass) over the entire EMA;
9. To protect the EMA from vehicle access (fence off if necessary);
10. To erect a minimum of two Warning Signs along the edge of the EMA. Refer to Section 6.8;
11. To preferentially select low phosphorus, liquid detergents; and
12. To install and manage the wastewater system according to the details of this report, its appendices and the manufacturer's recommendations.

**Note: This system design might be altered slightly by the Conditions of Consent. It is the responsibility of the owner/builder to check the conditions of consent prior to commencing works.**

## 7 SYSTEM DESIGN

**Note: The system design might be altered slightly by the Conditions of Consent - it is important to check these before work commences.**

This design assumes a certain design wastewater load. It will be invalidated if that load were to significantly increase (>10 percent): This might occur due to (but not limited to):


- If a spa bath or in-sink food grinder were installed.
- If a home is occupied by more than 2 persons per bedroom.
- If water fixtures are not at least three-star rated.
- If plumbing leaks are not attended to.

The design is warranted to meet the required design guidelines and standards at the time of writing. However, that does not preclude the requirement of the land owner to satisfactorily use and maintain the system to the requirements of the manufacturers and to the generic guidelines given in the following Appendix. In particular there are requirements to:

- Ensure that only “septic-friendly” substances are disposed into the system (materials and chemicals).
- Periodically (once per 3-5 years) clean out the septic tank or septic chamber of the AWTs.
- Regularly (once per three months) clean the septic outlet filter or the in-line filter.
- Regularly (once per three months) manually flush the system.
- Periodically (one per year) check the disposal area for signs of seepage.
- Periodically (one per year) check the upslope diversion drain (if applicable) to ensure stormwater is adequately diverted.

Your system will be inspected as required by Council. The Wastewater Contractor must inspect both the treatment system and the disposal area following the checklist given in Appendix 1 and submit the results to Council. Should there be a problem with your system you must initially consult the licensed contractors who installed the system and/or your regular maintenance contractor.





**TYPICAL SEMI-FIXED SPRAY  
IRRIGATION DESIGN**

**Figure 2 - Proposed Disposal System (Typical details). This Figure must be read in conjunction with the accompanying report by SEEC.**

## 8 REFERENCES

Department of Local Government (1998). Environment and Health Protection Guidelines: *Onsite Sewage Management for Single Household*.

eSPADE (2020). NSW Office of Environment and Heritage.

Penrith City Council (2014). *On-site Sewage Management and Greywater Reuse Policy*

Standards Australia / Standards New Zealand (2012). AS/NZS 1547:2012 *On-site Domestic Wastewater Management*.

WaterNSW (2015). *Neutral or Beneficial Effect on Water Quality Assessment Guideline*.

WaterNSW (2015) *Neutral or Beneficial Effect on Water Quality Assessment Tool*  
CONSULTANTS AND CONSULTANT ADMINISTRATORS

WaterNSW (2018). *Developments in the Sydney Drinking Water Catchment – Water Quality Information Requirements*.

WaterNSW (2019). *Designing and Installing On-Site Wastewater Systems. A WaterNSW Current Recommended Practice*.

## 9 APPENDICES

### 9.1 Appendix 1: Penrith City Council Overland Flow Path



Our reference: ECM 9081647  
Contact: Dr Elias Ishak  
Telephone: (02) 4732 7579

2 April 2020

Ms Kim Passfield  
68-70 Station Street  
BOWRAL NSW 2576

Dear Ms Passfield

**Flood Level Enquiry  
Lot 5 DP 655046 - No. 344 Park Road, Wallacia**

Please find enclosed Flood Level information for the above property.

Should you require any further information please do not hesitate to contact me on 4732 7579.

Yours sincerely

Dr Elias Ishak  
Acting Engineering Stormwater Supervisor

Penrith City Council  
PO Box 60, Penrith  
NSW 2751 Australia  
T 4732 7777  
F 4732 7958  
penrithcity.nsw.gov.au

**PENRITH**  
CITY COUNCIL

PENRITH

# Flood Information Lot 5 DP 655046 - No. 344 Park Road, Wallacia

Date of issue: 2 April 2020

The 1% AEP local overland flow flood levels affecting the above property are as indicated on the map below in white colour.

Property less than 0.5m above the 1% AEP flood level is subject to Penrith Development Control Plan 2014 Section C3.5 Flood Planning. The Penrith Development Control Plan 2014 is available from Council's website [www.penrithcity.nsw.gov.au](http://www.penrithcity.nsw.gov.au).



Penrith City Council  
PO Box 60, Penrith  
NSW 2751 Australia  
T 4732 7777  
F 4732 7958  
[penrithcity.nsw.gov.au](http://penrithcity.nsw.gov.au)

## Definitions

**AEP** – Annual Exceedance Probability – the chance of a flood of this size occurring in any one year.

**AHD** – Australian Height Datum – A standard level datum used throughout Australia, approximately equivalent to mean sea level.

**PENRITH**  
CITY COUNCIL



**Legend**

	Extent of 1% AEP local catchment overland flow path. Generally depths less than 150mm is not shown.
--	---

**Notes:**

1. The contours shown above in yellow numbering are at 0.5m intervals and are based on Aerial Laser Scanning (ALS) Survey undertaken in 2002. The contour levels are approximate and for general information only. Accurate ground levels should be obtained by a Registered Surveyor.
2. The flood level is based on current information available to Council at the date of issue. The flood level may change in the future if new information becomes available. The 1% AEP flood is the flood adopted by Council for planning controls. Rarer and more extreme flood events will have a greater effect on the property.
3. You are strongly advised if you propose to carry out development upon the property, that you retain the assistance of an experienced flooding engineer and have carried out a detailed investigation.
4. Council accepts no liability for the accuracy of the flood levels (or any other data) contained in this certificate, having regard to the information disclosed in Notes "1", "2". As such you should carry out and rely upon your own investigations.

\_\_\_\_\_  
**Dr Elias Ishak**  
**Acting Engineering Stormwater Supervisor**

Penrith City Council  
 PO Box 60, Penrith  
 NSW 2751 Australia  
 T 4732 7777  
 F 4732 7958  
 penrithcity.nsw.gov.au

**PENRITH**  
 CITY COUNCIL

## 9.2 Appendix 2: Annual Checklist for Owners

<b>Checklist 13.2 Operation inspection<sup>(1)</sup> of land application area for use by service agents, Council inspectors and system owners</b>		
Does the system owner have a set of plans of the irrigation system and an Operational and Maintenance Manual?	<input type="checkbox"/> Yes	<input type="checkbox"/> No
<b>Land Application Area</b>		
Is there evidence of irrigation area damage by vehicle, livestock or domestic animal activities?	<input type="checkbox"/> Yes <input type="checkbox"/> No	Comment:
Is a good vegetation cover established over the effluent irrigation area?	<input type="checkbox"/> Yes <input type="checkbox"/> No	Comment:
Are there any green or boggy areas or surface ponding of effluent liquid in the irrigation area?	<input type="checkbox"/> Yes <input type="checkbox"/> No	Comment:
Are there dry areas or areas lacking vegetation in the irrigation area?	<input type="checkbox"/> Yes <input type="checkbox"/> No	Comment:
Is the effluent irrigation area associated with an unpleasant smell that would suggest untreated or poorly treated effluent is being used to irrigate?	<input type="checkbox"/> Yes <input type="checkbox"/> No	Comment:
Has the effluent irrigation area been mown to maintain the grass short?	<input type="checkbox"/> Yes	<input type="checkbox"/> No
<b>Treatment and Irrigation System</b>		
Is any stormwater run-on effectively diverted around the irrigation area?	<input type="checkbox"/> Yes	<input type="checkbox"/> No
Is the irrigation pump working?	<input type="checkbox"/> Yes	<input type="checkbox"/> No
Is the irrigation system working without leaks?	<input type="checkbox"/> Yes	<input type="checkbox"/> No
Has the effluent irrigation area been back flushed?	<input type="checkbox"/> Yes	<input type="checkbox"/> No
Have the irrigation filters been checked and cleaned?	<input type="checkbox"/> Yes	<input type="checkbox"/> No
Does the system require air bleeding?	<input type="checkbox"/> Yes	<input type="checkbox"/> No
If an automatic sequencing valve is fitted, does it appear to switch between the different fields sequentially?	<input type="checkbox"/> Yes	<input type="checkbox"/> No
If a manual valve is fitted, has it been switched between the different fields?	<input type="checkbox"/> Yes	<input type="checkbox"/> No
Is the irrigation area still adequately protected from livestock, vehicles, children etc through the use of fencing, or shrub barriers etc.	<input type="checkbox"/> Yes	<input type="checkbox"/> No
Is there any inappropriate use of the irrigation area eg vegetable growing?	<input type="checkbox"/> Yes	<input type="checkbox"/> No
<b>Note, if as a system owner, you answered 'No' to any of the above questions, or there are any other problems, you should contact your service provider immediately.</b>		
<b>Service provider:</b>		
<b>Contact number:</b>		



## 9.3 Appendix 3: Fact Sheets for Owners

# Managing Wastewater In Your Backyard

### Reducing water usage

Reducing water usage will lessen the likelihood of problems such as overloading with your septic system. Overloading may result in wastewater backing up into your house, contamination of your yard with improperly treated effluent, and effluent from your system contaminating groundwater or a nearby waterway.

Your sewage management system is also unable to cope with large volumes of water such as several showers or loads of washing over a short period of time. You should try to avoid these 'shock loads' by ensuring water use is spread more evenly throughout the day and week.

### HELP PROTECT YOUR HEALTH AND THE ENVIRONMENT

Poorly maintained sewage management systems are a serious source of water pollution and may present health risks, cause odours and attract vermin and insects.

By looking after your management system you can do your part in helping to protect the environment and the health of you and your community.


For more information please contact:

### DO

- ✓ Learn how your sewage management system works and its operational and maintenance requirements.
- ✓ Learn the location and layout of your sewage management system.
- ✓ Have your AWTs (if installed) inspected and serviced four times per year by an approved contractor. Other systems should be inspected at least once every year. Assessment should be applicable to the system design.
- ✓ Keep a record of desludgings, inspections, and other maintenance.
- ✓ Have your septic tank or AWTs desludged every three years to prevent sludge build up, which may 'clog' the pipes.
- ✓ Conserve water. Conservative water use around the house will reduce the amount of wastewater which is produced and needs to be treated.
- ✓ Discuss with your local council the adequacy of your existing sewage management system if you are considering house extensions for increased occupancy.

### DON'T

- ✗ Don't let children or pets play on land application areas.
- ✗ Don't water fruit and vegetables with effluent.
- ✗ Don't extract untreated groundwater for cooking and drinking.
- ✗ Don't put large quantities of bleaches, disinfectants, whiteners, nappy soakers and spot removers into your system via the sink, washing machine or toilet.
- ✗ Don't allow any foreign materials such as nappies, sanitary napkins, condoms and other hygiene products to enter the system.
- ✗ Don't put fats and oils down the drain and keep food waste out of your system.
- ✗ Don't install or use a garbage grinder or spa bath if your system is not designed for it.



## ON-SITE SEWAGE MANAGEMENT SYSTEMS

If you live in or rent a house that is not connected to the main sewer then chances are that your yard contains an on-site sewage management system. If this is the case then you have a special responsibility to ensure that it is working as well as it can.

The aim of this pamphlet is to introduce you to some of the most popular types of on-site sewage management systems and provide some general information to help you maintain your system effectively. You should find out what type of system you have and how it works.

More information can be obtained from the pamphlets:

Your Septic System  
Your Aerated Wastewater Treatment System  
Your Composting Toilet  
Your Land Application Area

You can get a copy of these pamphlets from your local council or the address marked on the back of this pamphlet.

It is important to keep in mind that maintenance needs to be performed properly and regularly. Poorly maintained on-site sewage management systems can significantly affect you and your family's health as well as the local environment.

### What is an on-site sewage management system?

A domestic on-site sewage management system is made up of various components which - if properly designed, installed and maintained - allow the treatment and utilisation of wastewater from a house, completely within the boundary of the property.

Wastewater may be blackwater (toilet waste), or greywater (water from showers, sinks, and washing machines), or a combination of both.

Partial on-site systems - eg. pump out and common effluent systems (CES) - also exist. These usually involve the preliminary on-site treatment of wastewater in a septic tank, followed by collection and transport of the treated wastewater to an off-site management facility. Pump out systems use road tankers to transport the effluent, and CES use a network of small diameter pipes.

### How does an on-site sewage management system work?

For complete on-site systems there are two main processes:

1. treatment of wastewater to a certain standard
2. its application to a dedicated area of land.

The type of application permitted depends on the quality of treatment, although you should try to avoid contact with all treated and untreated wastewater, and thoroughly wash affected areas if contact does occur.

Treatment and application can be carried out using various methods:

#### Septic Tank

Septic tanks treat both greywater and blackwater, but they provide only limited treatment through the settling of solids and the flotation of fats and greases. Bacteria in the tank break down the solids over a period of time. Wastewater that has been treated in a septic tank can only be applied to land through a covered soil absorption system, as the effluent is still too contaminated for above ground or near surface irrigation.

#### AWTS

Aerated wastewater treatment systems (AWTS) treat all household wastewater and have several treatment compartments. The first is like a septic tank, but in the second compartment air is mixed with the wastewater to assist bacteria to break down solids. A third compartment allows settling of more solids and a final chlorination contact chamber allows disinfection. Some AWTS are constructed with all the compartments inside a single tank. The effluent produced may be surface or sub-surface irrigated in a dedicated area.

#### Composting Toilets

Composting toilets collect and treat toilet waste only. Water from the shower, sinks and the washing machine needs to be treated separately (for example in a septic tank or AWTS as above). The compost produced by a composting toilet has special requirements but is usually buried on-site.

These are just some of the treatment and application methods available, and there are many other types such as sand filter beds, wetlands, and amended earth mounds. Your local council or the NSW Department of Health have more information on these systems if you need it.

### Regulations and recommendations

The NSW Department of Health determines the design and structural requirements for treatment systems for single households. Local councils are primarily responsible for approving the installation of smaller domestic septic tank systems, composting toilets and AWTS in their area, and are also responsible for approving land application areas. The NSW Environment Protection Authority approves larger systems.

The design and installation of on-site sewage management systems, including plumbing and drainage, should only be carried out by suitably qualified or experienced people. Care is needed to ensure correct sizing of the treatment system and application area.

Heavy fines may be imposed under the Clean Waters Act if wastewater is not managed properly.

### Keeping your on-site sewage management system operating well

What you put down your drains and toilets has a lot to do with how well your system performs. Maintenance of your sewage management system also needs to be done well and on-time. The following is a guide to the types of things you should and should not do with your system.

# Your Aerated Wastewater Treatment System

Odour problems from a vent on the AWTS can be a result of slow or inadequate breakdown of solids. Call a technician to service the system.

## HELP PROTECT YOUR HEALTH AND THE ENVIRONMENT

Poorly maintained AWTSs are a serious source of water pollution and may present health risks, cause odours and attract vermin and insects.

By looking after your treatment system you can do your part in helping to protect the environment and the health of you and your family.

If you would like more information please contact:

## Reducing water usage

Reducing water usage will lessen the likelihood of problems such as overloading with your AWTS. Overloading may result in wastewater backing up into your house, contamination of your yard with improperly treated effluent, and effluent from your system entering a nearby river, creek or dam.

Conservative water use around the house will reduce the amount of wastewater which is produced and needs to be treated.


Your AWTS is also unable to cope with large volumes of water such as several showers or loads of washing over a short period of time. You should try to avoid these 'shock loads' by ensuring water use is spread more evenly throughout the day and week.

## Warning signs

You can look out for a few warning signs that signal to you that there are troubles with your AWTS. Ensure that these problems are attended to immediately to protect your health and the environment.

Look out for the following warning signs:

- ⚠ Water that drains too slowly.
- ⚠ Drain pipes that gurgle or make noises when air bubbles are forced back through the system.
- ⚠ Sewage smells, this indicates a serious problem.
- ⚠ Water backing up into your sink which may indicate that your system is already failing.
- ⚠ Wastewater pooling over the land application area.
- ⚠ Black coloured effluent in the aerated tank.
- ⚠ Excess noise from the blower or pumping equipment
- ⚠ Poor vegetation growth in irrigated area.



## Aerated Wastewater Treatment Systems (AWTS)

In unsewered areas, the proper treatment and utilisation of household wastewater on-site is critical in preserving the health of the public and the environment. AWTS have been developed as a way of achieving this.

### What is an AWTS?

An AWTS is a purpose built system used for the treatment of sewage and liquid wastes from a single household or multiple dwellings.

It consists of a series of treatment chambers combined with an irrigation system. An AWTS enables people living in unsewered areas to treat and utilise their wastewater.

### How does an AWTS work?

Wastewater from a household is treated in stages in several separate chambers. The first chamber is similar to a conventional septic tank. The wastewater enters the chamber where the solids settle to the bottom and are retained in the tank forming a sludge layer. Scum collects at the top, and the partially clarified wastewater flows into a second chamber. Here the wastewater is mixed with air

to assist bacteria to further treat it. A third chamber allows additional clarification through the settling of solids, which are returned for further treatment to either the septic chamber (as shown) or to the aeration chamber. The clarified effluent is disinfected in another chamber (usually by chlorination) before irrigation can take place.

Bacteria in the first chamber break down the solid matter in the sludge and scum layers. Material that cannot be fully broken down gradually builds up in the chamber and must be pumped out periodically.

### Regulations and recommendations


Local councils are primarily responsible for approving the smaller, domestic AWTSs in their area. The Environment Protection Authority (EPA) approves larger units, whilst the NSW Department of Health determines the design and structural requirements for all AWTSs.

At present AWTSs need to be serviced quarterly by an approved contractor at a cost to the owner. Local councils should also maintain a register of the servicing of each system within their area.

AWTSs should be fitted with an alarm having visual and audible components to indicate mechanical and electrical equipment malfunctions. The alarm should provide a signal adjacent to the alarm and at a relevant position inside the house. The alarm should incorporate a warning lamp which may only be reset by the service agent.

### Maintaining your AWTS

The effectiveness of the system will, in part, depend on how it is used and maintained. The following is a guide on good maintenance procedures that you should follow:



### DO

- ✓ Have your AWTS inspected and serviced four times per year by an approved contractor. Assessment should be applicable to the system design.
- ✓ Have your system service include assessment of sludge and scum levels in all tanks, and performance of irrigation areas.
- ✓ Have all your tanks desludged at least every three years.
- ✓ Have your disinfection chamber inspected and tested quarterly to ensure correct disinfectant levels.
- ✓ Have your grease trap (if installed) cleaned out at least every two months.
- ✓ Keep a record of pumping, inspections, and other maintenance.
- ✓ Learn the location and layout of your AWTS and land application area.
- ✓ Use biodegradable liquid detergents such as concentrates with low sodium and phosphorous levels.
- ✓ Conserve water.

### DON'T

- ✗ Don't put bleaches, disinfectants, whiteners, nappy soakers and spot removers in large quantities into your AWTS via the sink, washing machine or toilet.
- ✗ Don't allow any foreign materials such as nappies, sanitary napkins, condoms and other hygiene products to enter the system.
- ✗ Don't use more than the recommended amounts of detergents.
- ✗ Don't put fats and oils down the drain and keep food waste out of your system.
- ✗ Don't switch off power to the AWTS, even if you are going on holidays



## Maintaining your land application area

The effectiveness of the application area is governed by the activities of the owner.

### DO

- ✓ Construct and maintain diversion drains around the top side of the application area to divert surface water.
- ✓ Ensure that your application area is kept level by filling any depressions with good quality top soil (not clay).
- ✓ Keep the grass regularly mowed and plant small trees around the perimeter to aid absorption and transpiration of the effluent.
- ✓ Ensure that any run off from the roof, driveway and other impermeable surfaces is directed away from the application area.
- ✓ Fence irrigation areas.
- ✓ Ensure appropriate warning signs are visible at all times in the vicinity of a spray irrigation area.
- ✓ Have your irrigation system checked by the service agent when they are carrying out service on the treatment system.

### DON'T

- ✗ Don't erect any structures, construct paths, graze animals or drive over the land application area.
- ✗ Don't plant large trees that shade the land application area, as the area needs sunlight to aid in the evaporation and transpiration of the effluent.
- ✗ Don't plant trees or shrubs near or on house drains.
- ✗ Don't alter stormwater lines to discharge into or near the land application area.
- ✗ Don't flood the land application area through the use of hoses or sprinklers.
- ✗ Don't let children or pets play on land application areas.
- ✗ Don't water fruit and vegetables with the effluent.
- ✗ Don't extract untreated groundwater for potable use.

## Warning signs

Regular visual checking of the system will ensure that problems are located and fixed early.

The visual signs of system failure include:

- ⚠ surface ponding and run-off of treated wastewater
- ⚠ soil quality deterioration
- ⚠ poor vegetation growth
- ⚠ unusual odours

## Volume of water

Land application areas and systems for on-site application are designed and constructed in anticipation of the volume of waste to be discharged. Uncontrolled use of water may lead to poorly treated effluent being released from the system.

If the land application area is waterlogged and soggy the following are possible reasons:

- ⚠ Overloading the treatment system with wastewater.
- ⚠ The clogging of the trench with solids not trapped by the septic tank. The tank may require desludging.
- ⚠ The application area has been poorly designed.
- ⚠ Stormwater is running onto the area.


## HELP PROTECT YOUR HEALTH AND THE ENVIRONMENT

Poorly maintained land application areas are a serious source of water pollution and may present health risks, cause odours and attract vermin and insects.

By looking after your sewage management system you can do your part in helping to protect the environment and the health of you and your family.

For more information please contact:

# Your Land Application Area



## LAND APPLICATION AREAS

The reuse of domestic wastewater on-site can be an economical and environmentally sound use of resources.

### What are land application areas?

These are areas that allow treated domestic wastewater to be managed entirely on-site.

The area must be able to utilise the wastewater and treat any organic matter and wastes it may contain. The wastewater is rich in nutrients, and can provide excellent nourishment for flower gardens, lawns, certain shrubs and trees. The vegetation should be suitably tolerant of high water and nutrient loads.

### How does a land application area work?


Treated wastewater applied to a land application area may be utilised or simply disposed, depending on the type of application system that is used. The application of the wastewater can be through a soil absorption system (based on disposal) or through an irrigation system (based on utilisation).

**Soil absorption systems** do not require highly treated effluent, and wastewater treated by a septic tank is reasonable as the solids content in the effluent has been reduced. Absorption systems release the effluent into the soil at a depth that cannot be reached by the roots of most small shrubs and grasses. They rely mainly on the processes of soil treatment and then transmission to the water table, with minimal evaporation and up-take by plants. **These systems are not recommended in sensitive areas as they may lead to contamination of surface water and groundwater.**

**Irrigation systems** may be classed as either subsurface or surface irrigation. If an irrigation system is to be used, wastewater needs to be pre-treated to at least the quality produced by an aerated wastewater treatment system (AWTS).

**Subsurface irrigation** requires highly treated effluent that is introduced into the soil close to the surface. The effluent is utilised mainly by plants and evaporation.

*Surface irrigation* requires highly treated effluent that has undergone aeration and disinfection treatments, so as to reduce the possibility of bacteria and virus contamination.



The effluent is then applied to the land area through a series of drip, trickle, or spray points which are designed to eliminate airborne drift and run-off into neighbouring properties.

There are some public health and environmental concerns about surface irrigation. There is the risk of contact with treated effluent and the potential for surface run-off. Given these problems, subsurface irrigation is arguably the safest, most efficient and effective method of effluent utilisation.

### Regulations and recommendations

The design and installation of land application areas should only be carried out by suitably qualified or experienced people, and only after a site and soil evaluation is done by a soil scientist. Care should be

taken to ensure correct buffer distances are left between the application area and bores, waterways, buildings, and neighbouring properties.

Heavy fines may be imposed under the Clean Waters Act if effluent is managed improperly.

At least two warning signs should be installed along the boundary of a land application area. The signs should comprise of 20mm high Series C lettering in black or white on a green background with the words:

**RECLAIMED EFFLUENT  
NOT FOR DRINKING  
AVOID CONTACT**

Depending on the requirements of your local council, wet weather storage and soil moisture sensors may need to be installed to ensure that effluent is only irrigated when the soil is not saturated.

Regular checks should be undertaken of any mechanical equipment to ensure that it is operating correctly. Local councils may require periodic analysis of soil or groundwater characteristics

Humans and animals should be excluded from land application areas during and immediately after the application of treated wastewater. The longer the period of exclusion from an area, the lower the risk to public health.

The householder is required to enter into a service contract with the installation company, its agent or the manufacturer of their sewage management system, this will ensure that the system operates efficiently.

### Location of the application area

Treated wastewater has the potential to have negative impacts on public health and the environment. For this reason the application area must be located in accordance with the results of a site evaluation, and approved landscaping must be completed prior to occupation of the building. Sandy soil and clayey soils may present special problems.

The system must allow even distribution of treated wastewater over the land application area.